



PRODUCT  
INSTRUCTIONS

# EX\_EXTERNAL SUPERIOR PLATE SEPARATOR




**CUMSA**  
INNOVATIVE SOLUTIONS  
FOR YOUR MOLDS

## WHAT'S INCLUDED IN THE PACKAGE




## EX\_ONE PRODUCT TWO APPLICATION OPTIONS LEADING DOUBLE EJECTION INSTALLATION


1



2




3




## EX\_ONE PRODUCT TWO APPLICATION OPTIONS THREE PLATE MOLD INSTALLATION


1



2




3





## EX\_CORE INSTALLATION


1



2




2.1




2.2

3




## EX\_CORE INSTALLATION


4



5





6



## EX\_CORE INSTALLATION

7


2nd STROKE



7.1

Check "Unlocking the shaft" section

## EX\_EXTERNAL INSTALLATION



Using **EB** component.

## EX\_UNLOCKING THE SHAFT

