

ES Doble Expulsión DE Zweistufenauswerfer
IT Doppia Espulsione PT Dupla Extracção FR Double Ejection

DE




Ref.	CR(N)	SWa	SWb
DE.243648	3.800	5	8

IMPORTANT !

Use the scale to adjust the first opening from 5 to 30mm.
 Utilice la escala para ajustar la primera carrera de 5 a 30mm.
 Verwenden Sie die Skala, um den ersten Hub von 5 bis 30mm. einzustellen.
 Utilizzare la regolazione per impostare la prima corsa da 5 a 30mm.
 Utilize a escala para definir o primeiro curso de 5 a 30mm.
 Utilisez l'échelle pour régler la première course de 5 à 30mm.

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

IMPORTANT !



Adjustable 1st opening
Ajustable en la 1^a apertura
Werkzeug öffnet Trenneber
1^a apertura regolabile.
1^a abertura ajustavel
1^{ère} ouverture ajustable

And free 2nd Opening
Y 2^a Apertura libre
Und freien 2. Hub
E una 2^a corsa libera
E um 2^o curso livre
Puis un 2^{ème} mouvement libre

