

**ES Varilla Expulsora DE Auswerfer ohne Kopf**  
**IT Asta Espulsore PT Extractor sem Cabeça FR Ejecteur sans Tête**

VE



Indicate the desired **L** dimension after the reference.  
Indicar la cota **L** necesaria después de la referencia.  
Gewünschte Länge **L** angeben.  
Indicare la quota **L** desiderata dopo il codice.  
Indique a dimensão **L** desejada depois da referência.  
Indiquer longueur **L** désirée après référence.

| Ref.      | A  | L   |     |
|-----------|----|-----|-----|
| VE.030... | 3  | 600 |     |
| VE.100... | 10 | 600 | 800 |

**ES Tubular Expulsión DE Auswerferhülsen ohne Kopf**  
**IT Espulsore Tubolare PT Extractor Tubular sem Cabeça FR Tubulaire sans Tête**

TE



Indicate the desired **L** dimension after the reference.  
Indicar la cota **L** necesaria después de la referencia.  
Gewünschte Länge **L** angeben.  
Indicare la quota **L** desiderata dopo il codice.  
Indique a dimensão **L** desejada depois da referência.  
Indiquer longueur (**L**) désirée après la référence.

| Ref.      | A  | B | E   | F  | L   |     |     |     |
|-----------|----|---|-----|----|-----|-----|-----|-----|
| TE.063... | 6  | 3 | 3.2 | 30 | 400 | 500 | 600 | 800 |
| TE.106... | 10 | 6 | 6.2 | 40 | 400 | 500 | 600 | 800 |
| TE.128... | 12 | 8 | 8.2 | 45 | 400 | 500 | 600 | 800 |