



EZ_EXTERNAL SYNCHRONIZED PLATES




WHAT'S INCLUDED IN THE PACKAGE




EZ_PRODUCT APPLICATION OPTIONS SYNCHRONIZED PLATES INSTALLATION


1



2




3





EZ_CORE INSTALLATION


1



2





2.1




2.2

3




3.1




3.2

EZ_CORE INSTALLATION



4



5




6



6.1

Check "Unlocking the shaft" section

EZ_EXTERNAL INSTALLATION



Using **EB** component.

CUMSA

INNOVATIVE SOLUTIONS
FOR YOUR MOLDS

EZ_UNLOCKING THE SHAFT

